

# sanwa

勝特力材料 886-3-5753170

勝特力电子(上海) 86-21-54151736

勝特力电子(深圳) 86-755-83298787

[Http://www.100y.com.tw](http://www.100y.com.tw)

## **DM508S DM1008S PDM508S**

**INSULATION RESISTANCE TESTER**

**INSTRUCTION MANUAL**

**SANWA ELECTRIC  
INSTRUMENT CO., LTD.**

Dempa Bldg., Sotokanda 2-Chome  
Chiyoda-Ku, Tokyo, Japan





## [1] Read First: Safety Information

We thank you for your purchasing our product, the battery-driven insulation resistance tester.

This is a DC resistance tester developed under the principle to provide new and unique design and function for the measurement of insulation resistance of each kind of electric equipments. Since this tester generates high voltage, we recommend that you read this instruction manual thoroughly, and treat the tester correctly and safely.

The symbols used on this tester and in this instruction manual denote the following meanings:

-  Be careful as the high voltage is impressed.
-  Be careful because there is a possibility of bodily injury or the destruction of equipment.

### WARNING

To ensure that the meter is used safely, follow all safety and operating instructions.

1. Never use tester for high power or high voltage circuit.
2. Pay special attention when measuring the voltage of AC 30Vrms (42.4V Peak) or DC 60V or more to avoid injury.
3. Disconnect power source of the measured circuit before measuring insulation resistance.
4. High voltage is generated while measuring insulation resistance. Be cautious of electric shock.
5. After measuring insulation to avoid electric shock. Be sure to discharge the high voltage charged.
6. Never apply an input signal exceeding the maximum rating input value.
7. Never use tester for measuring the line connected with equipment (i.e. motors) that generates induced or surge voltage since it may exceed the maximum allowable voltage.
8. Never use tester if the tester or test leads are damaged or broken.
9. Never use uncased tester.
10. Always keep your fingers behind the finger guards on the probe when making measurements.

11. Be sure to disconnect the test pin from the circuit when changing the function.
12. Never use tester with wet hands or in a damp environment.
13. Never use test leads other than the exclusive test leads.
14. Never open tester case except when replacing batteries or fuses. Do not attempt any alterations of original specifications.
15. To ensure safety and maintain accuracy, calibrate and check the tester at least once a year.
16. Indoor use.

**⚠ CAUTION**

High voltage is generated in terminals of insulation resistance testers when measuring insulation resistance. (There may be possibility to damage the measuring object when measurement). Remove components such as semiconductors from the circuit of measuring object to avoid damages when withstand of the object is unknown or lower than rated measuring voltage of a resistance insulation tester.

**Maximum Overload Protection Input**

Function (Range)	Maximu rating input value	Maximum overload protection input
ACV (600)	AC600V	AC720V
DCV(60)	DC60V	AC600V

勝特力材料 886-3-5753170  
 勝特力电子(上海) 86-21-54151736  
 勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)

## **[2] Applications and Features**



### **2.1 Applications**

- DC insulation resistance tester to measure the insulation resistance of electric lines and electric equipment.

### **2.2 Features**

- This tester is based on the revised standard JIS C1302-1994 Insulation resistance testers.
- It is equipped with the discharge function.
- It is equipped with the MΩ (insulation resistance) measuring switch that enables both one-shot and continuous measurement.

### [3] Front View and Name of Each Part




#### [4] Description of Functions

- Function control knob and  $M\Omega$  (insulation resistance) measuring switch by operating these two switches, the functions and ranges can be set as shown below.

Position of Function Control Knob		$M\Omega$ Measuring Switch (*)	Set Range (Function)
DM508S	500V/1000M $\Omega$	AC 600V	OFF
DM1008S	1000V/2000M $\Omega$		
PDM508S	500V/100M $\Omega$		
DM508S	500V/1000M $\Omega$	AC 600V	ON
DM1008S	1000V/2000M $\Omega$		
PDM508S	500V/100M $\Omega$		
BATTERY CHECK		ON	BATTERY CHECK
DC60V		OFF	DC60V

- \* The  $M\Omega$  measuring switch is turned on by the following operation.
- ON only when the right end of the lever is pressed with a finger. (OFF when the finger is released)
  - Continuously ON when the left end of the lever is raised. (OFF when it is laid down)




- Meter zero position adjustment  
 If the meter pointer is not on the  $\infty$  graduation line of the  $M\Omega$  scale when the function control knob is at OFF, adjust the zero position with a screwdriver.

## How To Use Carrying Case

During measurement, set the case as illustrated and hang it from the neck.

- Lid turns in direction at pivot the A.
- Lay it along the bottom of the box and secure it by hooks marked by\*



## [5] Measuring Method


### 5.1 Start-up Check

#### ⚠ WARNING

1. Do not use a damaged tester or test lead.
2. Make sure test lead wiring is not broken.
3. When testing the continuity of a test lead, the measuring terminals are under a high voltage. Be careful of electric shock.
4. To prevent electric shock and battery consumption, be sure to turn the  $M\Omega$  measuring switch and function control knob to OFF after measurement.

勝特力材料 886-3-5753170  
勝特力电子(上海) 86-21-54151736  
勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)

Before starting measurement, check the “appearance”, “pointer 0 position”(\*), “built-in battery” and “measuring lead” in this order. (\*The pointer 0 position is the 0 position of the DC60V scale or  $\infty$  position of the M $\Omega$  scale.)



## 5.2 How to Check Bult-in Battery (BATTERY CHECK)

Prior to M $\Omega$  (insulation resistance) measurement, be sure to check the built-in battery. A consumed battery will cause not only measurement errors but danger due to erroneous measurement.

For checking methods, refer to 5.1 Start-up Check.

**⚠ Do not check the built-in battery for more than 5 seconds.**

勝特力材料 886-3-5753170  
 勝特力电子(上海) 86-21-54151736  
 勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)

### 5.3 Measurement of MΩ (Insulation Resistance)

#### ⚠ WARNING

1. Never apply a voltage to the measuring terminal when the tester is in the MΩ measuring range.
2. Prior to measurement, disconnect the measuring object (circuit) from the power supply.
3. Prior to measurement, make sure no voltage is applied to the circuit to measure by the AC600V range.
4. During measurement, a high voltage is generated. Do not touch the test pin, clip and measuring object.
5. The tester and measured circuit have been charged by high voltage immediately after the measurement. Be careful not to get electric shock.
6. There is a possibility of an accident of electric shock. After the measurement, be sure to discharge the high voltage charged in the measuring object. (See 5.4 Discharge Function)

#### ⚠ CAUTION

1. When the measuring object is grounded (earth), a normal practice is to connect the lead with clip (EARTH) to ground (earth) and the lead with test pin (LINE) to the circuit. (When this connection is used, a measurement value becomes smaller than a value obtained by the reverse connection.)
2. To prevent a measuring error, keep the test lead connected to the LINE side out of contact with the measuring object and ground (earth).
3. The insulation resistance varies largely depending on temperature and humidity. It is also influenced by a voltage to apply (measuring voltage).  
Normally as temperature, humidity and voltage increase, the insulation resistance decreases.

勝特力材料 886-3-5753170  
勝特力电子(上海) 86-21-54151736  
勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)



## ⚠ REFERENCE

1. The rated measuring current of this tester is 1 mA. (1 mA to 1.2 mA when the resistance of a value below the rated measuring voltage/1 mA and within 1st effective measurement scale is measured.)
2. The no-load voltage is within 1.3 times the rated measuring voltage.
3. While measuring there may be an oscillator noise from the meter, but this is not a malfunction.

- 1) Measuring object  
Measurement of insulation resistance ( $M\Omega$ ) of electric equipment and circuits.

- 2) Rated measuring voltage

Model	Rated measuring voltage
DM508S	500V
DM1008S	1000V
PDM508S	500V

勝特力材料 886-3-5753170  
勝特力电子(上海) 86-21-54151736  
勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)


- 3) Selection of a measuring range  
Turn the function control knob to ( $M\Omega$ ) / AC600V position.

- 4) Measuring method

- ① Power off the measuring object.
- ② Connect the lead with clip (black) to the earth side measuring terminal (EARTH) and the lead with test pin (red) to the line side measuring terminal (LINE).
- ③ Turn the function control knob to a desired rated measuring voltage range.
- ④ Connect the clip of the lead with clip to the measuring object. Normally, the earth side measuring terminal should be on the earth line side.
- ⑤ Bring the test pin of the lead with test pin in contact with the other side of the measuring object.

**⚠ CAUTION** : If the meter deflects in this state, the measuring object is charged. Be sure to remove the voltage prior to measurement.

- ⑥ Turn on the  $M\Omega$  measuring switch.  
(See [4] Description of Functions)
- ⑦ Read the indicated value. Use the  $M\Omega$  scale.
- ⑧ Turn off the  $M\Omega$  measuring switch.
- ⑨ Discharge the high voltage charged in the measuring object. See 5.4 Discharge Function.
- ⑩ First, disconnect the test pin of the lead with test pin from the measuring object. Then remove the clip of the lead with clip.
- ⑪ Be sure to turn the function control knob to the position of OFF.



**⚠ CAUTION**

Rated measuring voltage should be selected by a measuring object.  
For example, 125V rated measuring voltage should be used for the  
object, AC input voltage of which is 100V.

**勝特力材料 886-3-5753170**  
**勝特力电子(上海) 86-21-54151736**  
**勝特力电子(深圳) 86-755-83298787**  
**Http://www.100y.com.tw**

## 5.4 Discharge Function

### 1) Reason of a need to discharge

For safety, high voltage remaining in capacitive measuring objects such as capacitors and electric wire must be discharged to prevent accidents.

### 2) Discharging method

This procedure follows the step ⑧ of 5.3-4)

- ① When the  $M\Omega$  measurement has been completed, turn off only the  $M\Omega$  measuring switch with the test pin and the clip connected to the measuring object.
- ② Then the pointer deflects to the right and its deflection becomes smaller as time passes (indicating the charged charge is being discharged).
- ③ When the pointer stops at zero ( $\infty$  of the  $M\Omega$  scale) and discharge has been completed, conduct the steps ⑩ and ⑪ of 5.3-4)

**勝特力材料 886-3-5753170**

**勝特力电子(上海) 86-21-54151736**

**勝特力电子(深圳) 86-755-83298787**

**[Http://www.100y.com.tw](http://www.100y.com.tw)**

## 5.5 Measurement of ACV (AC voltage) (Measuring range is the AC600V range only)

### ⚠ WARNING

1. Do not apply a voltage exceeding the maximum rated voltage of 600 VAC.
2. During measurement, do not operate the function control knob.
3. Do not measure a voltage with the MΩ measuring switch being pressed or raised.
4. When the circuit to measure has a breaker, measure the voltage on the secondary side (load side).
5. To prevent electric shock, do not touch the metal part of the pin plug and clip.


### ⚠ CAUTION

AC voltages of waveforms other than sinusoidal waveforms and frequencies other than 50 to 60 Hz will cause an indication error.

- 1) Measuring object  
Sinusoidal AC voltages (ACV) such as lighting line voltages can be measured.

- 2) Measuring method

- ① Connect the lead with clip (black) to the earth side measuring terminal and the lead with test pin (red) to the line side measuring terminal.
- ② Turn the function control knob to AC600V.
- ③ Connect the lead with clip to the earth side of the circuit to measure and the lead with test pin to the charging side (line side).
- ④ Read the indicated value on the ACV scale.
- ⑤ Disconnect the lead with test pin and the lead with clip in this order from the measuring object.
- ⑥ Turn the function control knob to the position of OFF.



## 5.6 Measurement of DCV (DC voltage) (Measuring range is the DV60V range only)

### ⚠ WARNING


1. Do not apply a voltage exceeding the maximum rated voltage of 60 VDC.
2. Keep in mind the warnings of 5.5 described earlier.

### 1) Measuring object

DC voltages of batteries, etc. can be measured. Also, the tester can be used to check the presence of DC voltage prior to MΩ measurement.


### 2) Measuring method

- ① Connect the lead with clip (black) to the earth side measuring terminal and the lead with test pin (red) to the line side measuring terminal.
- ② Turn the function control knob to DC60V.
- ③ Connect the lead with clip (black) to the negative (—) side of the measuring object (circuit) and the lead with test pin (red) to the positive (+) side.
- ④ Read the indicated value on the DCV scale.
- ⑤ Disconnect the lead with test pin and the lead with clip in this order from the measuring object.
- ⑥ Turn the function control knob to the position of OFF.



## [6] Battery Replacement

- ① Remove two battery lid securing screws.
- ② Replace the consumed battery that is connected to the snap terminal with a new one.
- ③ Set the battery in the original place and secure the battery lid with screws.



⚠ Be sure to turn the function control knob to the position of OFF prior to replacing the battery.

⚠ Be sure to use the alkaline battery 6LR61 (9V).

## [7] Specifications

### 7.1 Measurement Range and Accuracy

Accuracy assurance : 23°C ± 2°C 45~75%RH max.

No condensation

Attitude : Horizontal (±5°)

Model	DM508S		DM1008S		PDM508S	
MΩ (Insulation) (Resistance) range	Rated measuring voltage		Large numeral : 1st effective measuring scale			
	Measuring value		Small numeral : 2nd effective measuring scale			
	500V 1000MΩ	0.5-1-500- 1000MΩ	1000V 2000MΩ	1-2-1000- 2000MΩ	500V 100MΩ	0.05-0.1- 50-100MΩ
ACV range	0~600V					
DCV range	0~60V					
Accuracy	<ul style="list-style-type: none"> <li>MΩ range                             <ul style="list-style-type: none"> <li>1st effective measurement range : ±5% of reading</li> <li>2nd effective measurement range : ±10% of reading</li> <li>0, ∞ scale : ±0.7% of scale length</li> <li>No load voltage : ±3% of rated measuring voltage</li> <li>Rated measuring current : 1~1.2mA</li> <li>Short circuit current : max 2mA</li> </ul> </li> </ul>					
	<ul style="list-style-type: none"> <li>ACV range (50/60Hz sine wave) : ±5% of full scale</li> </ul>					
	<ul style="list-style-type: none"> <li>DCV range : ±5% of full scale</li> </ul>					

勝特力材料 886-3-5753170

勝特力电子(上海) 86-21-54151736

勝特力电子(深圳) 86-755-83298787

[Http://www.100y.com.tw](http://www.100y.com.tw)

## 7.2 General Specifications

AC rectifying method	: Half-wave rectification (Mean value indication rms value converted)
Meter specification	: Inner-pole type taut-band system, 24 $\mu$ A (PDM508S:48 $\mu$ A)
Battery consumption	: Checked by BATTERY CHECK range.
Allowable temperature/humidity range	: 18~28 $^{\circ}$ C, 45~75% RH.
Service temperature/humidity	: 0~40 $^{\circ}$ C, 80% RH max., no condensation.
Storage temperature/humidity	: -10~50 $^{\circ}$ C, 70% RH max., no condensation.
Service ambient condition	: Altitude 2000 m max., environmental pollution II.
Built-in battery	: Layer built type alkaline battery 6LR61 x 1 (9V)
Max. power consumption	: 2.0W~2.8W at M $\Omega$ range
Continuous service hours	: DM508S            Approx 5.5hours (When indicating the center scale value of the M $\Omega$ range) DM1008S        Approx 3.5hours PDM508S        Approx 4.0hours
Applicable standard	: JIS C 1302-1994 Insulation resistance testers.
Safety standard	: IEC-1010-1(EN61010-1) Overvoltage category III, protection class II (600V AC/DC or less).
Withstand voltage	: 3.7 kV AC (one minute), between measuring terminal and rear case.
Size and weight	: 144(H) x 99 (W) x 43 (D) mm, approx. 310g
Accessories	: Test lead TL-508S, 1 set Instruction manual, 1 copy Carrying case C-08S, 1 piece

## [8] Storage

### CAUTION

- The panel and the case are not resistant to heat. Do not place the instrument near heat-generating devices (such as a soldering iron).
- Do not store the instrument in a place where it may be subjected to vibration or from where it may fall.
- For storing the instrument, avoid hot, cold or humid places or places under direct sunlight or where condensation is anticipated.

# sanwa

**SANWA ELECTRIC  
INSTRUMENT CO.,LTD.**

Dempa Bldg, Sotokanda2-Chome  
Chiyoda-Ku, Tokyo, Japan

勝特力材料 886-3-5753170

勝特力电子(上海) 86-21-54151736

勝特力电子(深圳) 86-755-83298787

[Http://www.100y.com.tw](http://www.100y.com.tw)