

勝特力材料 886-3-5753170  
勝特力电子(上海) 86-21-54151736  
勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)



**TECHSPRAY™**

Product Information

# TechPump Bottles

1980, 1981, 1982, 1983

## Introduction

---

TechPump bottles are designed for precision control and dispensing of solvents in electronic and laboratory environments. The distinctive pumping mechanism combined with a high density polyethylene (HDPE) bottle makes a complete unit ready for use with a broad range of cleaning solvents. The dish-type pump dispenser allows for a clean, one-handed operation, which prevents the use of excessive solvent and keeps contaminants from entering the container. The pump includes a hinged lid to keep out impurities while the container is not in use and stainless steel parts to facilitate the use of aggressive solvents. Precision valve seals contents to reduce vapor and product loss. To insure total purity, the unit is shipped with a celon band sealing the pump head.

## Chemical Components

---

This product does not contain any hazardous ingredients as per OSHA 29 CFR 1910.1200 Subpt.(z).

## Environmental Policy

---

Techspray® is committed to developing products to ensure a safer and cleaner environment. We will continue to meet and sustain the regulations of all federal, state and local government agencies.

## Packaging and Availability

---

Chrome Trigger Valve is available:

1980	4 Ounce Bottle with Pump
1981	6 Ounce Bottle with Pump
1982	8 Ounce Bottle with Pump
1983	6 Ounce Conductive Bottle with Pump

## Resources

---

Techspray® products are supported by a global sales, technical and customer services resources.

勝特力材料 886-3-5753170  
勝特力电子(上海) 86-21-54151736  
勝特力电子(深圳) 86-755-83298787  
[Http://www.100y.com.tw](http://www.100y.com.tw)

North America  
Tech Spray L.P.  
P.O. Box 949  
Amarillo, TX 79105  
800-858-4043  
email: [tsales@techspray.com](mailto:tsales@techspray.com)

Europe  
Techspray International  
UNIT 4, 44/46 Bunyan Road, Kempston  
Bedford MK42 8HL United Kingdom  
+44 (0) 1234 855443  
email: [tseurope@techspray.com](mailto:tseurope@techspray.com)

Countries Outside US  
Call to locate a distributor  
in your country.

Important Notice to Purchaser/User: The information in this publication is based on tests that we believe are reliable. The results may vary due to differences in tests type and conditions. We recommend that each user evaluate the product to determine its suitability for the intended application. Conditions of use are outside our control and vary widely. Techspray's only obligation and your only solution is replacement of product that is shown to be defective when you receive it. In no case will Techspray® be liable for any special, incidental, or consequential damages based on breach of warranty, negligence or any other theory.



Tech Spray, L.P.  
P.O. Box 949  
Amarillo, TX 79105

