

Products	Descriptions (Sizes etc.)	Article No.	POS Codes
Aerobics-2	(-)#5-75	ZAS5075	171537
	(-)#5-100	ZAS5100	171544
	(-)#6-100	ZAS6100	171643
	(-)#6-150	ZAS6150	171667
	(-)#8-150	ZAS8150	171865



How to use Aerobics-2

Use as Usual.

As The Insulated handle Model.

As The Go-Through Hammerable Model.

Use as Specialty for removing damaged Screw

In the cae of Some Slot remained.

Put and rotate toFind out Remaining Recessed on the head of screw.

While keeping the Found Position, make rotate tip for Loosen while pushing on.

If you feel few reaction, You should Hammer in order to get deeper response.

In case of Nothing left.

Put Tip of Alter-Minus Type on its hollow, then Hammer.

After Hammered, you shall be get New Slot for Alter-Plus Tip.

(Notice)

Applicable Range of Alter-Minus on Cross Reccess is as below.

*Alter-Minus(-)5.0mm is for Cross #2

*Alter-Minus(-)6mm's is for Cross #3

勝特力材料 886-3-5753170
 勝特力电子(上海) 86-21-54151736
 勝特力电子(深圳) 86-755-83298787
[Http://www.100y.com.tw](http://www.100y.com.tw)