Modulostar®

Helio



Advantages

- → Modulostar® fuse holder, with or without blown fuse indicator
 - → Specially designed for photovoltaics and D.C., applications in general
 - → Built to UL 512 and 60947-3 standards
 - → For fuses up to 32A 10x38
 - → Blown fuses indication from 350VDC to 1000VDC
 - → Plastic port are UL94 V0 to V2 (yellow card)
 - → In accordance with RoHS directive

Nb of pole	Cat. Number	Ref. Number	Nb of Mode (17.5mm)	Pack	Indicator
1	US101HEL	D1009979K	a COMA	12	Without Ind.
1.1	US101IHEL	Q1009461K	1 M.	12	With Ind.

Characteristics

- → Wiring: rigid wire = 1 16mm² (18-6AWG), flexible wire = 0.75 - 10mm² (18-8AWG) use 75°C wire CO only
- → Screw driver heads: Ferraz Shawmut recommends use of PZ 2 or flat 5.5x1mm heads (maximum diameter 6mm)
- → Maximum tightening torque: 2.2Nm
- → DC20B-IP2X

Nominal Voltage Ui DC	Voltage Isolation Uimp	Nominal Current	Max. power losses in the fuse links	Fuse links rating	Cable wire section (mm²) recommanded
	6kV	32A	3W	≤12	2.5
1000VDC	6kV	32A	3W	16	2.5
Pollution	6kV	32A	3W	20	2.5
Degree 2	6kV	32A	3W	25	CON 4
	6kV	32A	3W	30	CO6


Recommendetions


- → Do not operate under load
- → The PV source must be connected to the upstream terminal
- → Non insulated conductive parts: preferably the equipment should be laid out keeping the + and - polarities separate
- → Mounting with surge suppressors: check that the surge suppressors' Up is compatible with the US10's IU imp=6kV (see UTE C15-712)

勝 特 力 材 料 886-3-5753170 胜特力电子(上海) 86-21-34970699 胜特力电子(深圳) 86-755-83298787 Http://www.100y.com.tw

Accessories

Same as the entire Modulostar® range





Fuse clips

Cat. Number	Designation	Weight	Pack
MR10RESSORTCI	MR10 CI	4.5	200
MR10RESSORT	MR10	7.0	20
MR10RESSORTSP	MR10 without connecting lug	5.7	20



