

1500W True Sine Wave DC-AC Inverter with Solar Charger

TN-1500 series



- Features :
- True sine wave output (THD<3%)
- High surge power up to 3000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 91%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application : Home appliance, power tools, office and portable equipment, vehicle and yacht ...etc.
- Built-in solar / AC charger
- Optional monitoring software
- 2 years warranty



勝特力材料 886-3-5753170

胜特力电子(上海) 86-21-54151736

胜特力电子(深圳) 86-755-83298787

Http://www. 100y. com. tw

SPECIFICATION


MODEL		TN-1500-112	TN-1500-124	TN-1500-148	TN-1500-212	TN-1500-224	TN-1500-248		
-NI 100	RATED POWER (Typ.)	1500W	100		.100	COM.	- S I		
	MAXIMUM OUTPUT POWER (Typ.)								
OUTPUT		Factory setting set at 110VAC 100 / 110 / 115 / 120VAC selectable by setting button S.W			Factory setting set	at 230VAC	W7		
	AC VOLTAGE				200 / 220 / 230 / 24	200 / 220 / 230 / 240VAC selectable by setting button S.W			
	FREQUENCY	60±0.1Hz 50/60	Hz selectable by settir	ng button S.W	50±0.1%Hz 50/6	50±0.1%Hz 50/60Hz selectable by setting button S.W			
	WAVEFORM	True sine wave (TH	ID<3%) at rated input	voltage	WW.	COMP.			
	AC REGULATION (Typ.)	±3.0%							
	TRANSFER TIME	t<10ms inverter -	- by pass	WT	AN.	ANT.CO	MT.		
	SAVING MODE (Typ.)	Load \leq 5W will be	DN1						
	FRONT PANEL INDICATOR	Battery voltage lev	el, output load level, s	aving mode, fault and	operation status				
	BAT. VOLTAGE	12V	24V	48V	12V	24V	48V		
	VOLTAGE RANGE (Typ.)Note.1	10.5 ~ 15VDC	21 ~ 30VDC	42 ~ 60VDC	10.5 ~ 15VDC	21~30VDC	42~60VDC		
	DC CURRENT (Typ.) Note.5		75A	37.5A	150A	75A	37.5A		
PUT	NO LOAD DISSIPATION	\leq 18W @ standby saving mode							
	OFF MODE CURRENT DRAW								
	EFFICIENCY (Typ.) Note.2		89%	90%	88%	90%	91%		
	BATTERY TYPES	Open & sealed Lea				0070			
	FUSE	40A*5	30A*3	30A*2	40A*5	30A*3	30A*2		
BATTERY INPUT	BAT. LOW ALARM	11.3±4%	22.5±4%	45±4%	11.3±4%	22.5±4%	45±4%		
	BAT. LOW SHUTDOWN	10.5±4%	21±4%	42±4%	10.5±4%	21±4%	42±4%		
OTECTION	REVERSE POLARITY	By internal fuse op		+Z_+ 70	10.0_470	21=770	12-1/0		
	REVEROET OLARITT	82°C±5°C	82°C±5°C	96°C±5°C	68°C±5°C	68°C±5°C	68°C±5°C		
	OVER TEMPERATURE								
	OUTPUT SHORT	Protection type : Shut down o/p voltage, re-power on to recover ; by internal RTH3 detect on heatsink of power transistor							
JTPUT		Protection type : Shut down o/p voltage, re-power on to recover							
	OVER LOAD (Typ.)	105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec. Protection type : Shut down o/p voltage, re-power on to recover							
	CIRCUIT BREAKER	20A	iut down o/p voitage,	re-power on to recove					
		Optional (Only type	()	WWW.L	10A				
	GFCI PROCTECTION WORKING TEMP. Note.3		,	heo	None				
	WORKING HUMIDITY	0 ~ +40°C @ 100% load ; 60°C @ 50% load							
VIRONMENT		20% ~ 90% RH non-condensing							
	STORAGE TEMP., HUMIDITY	-30 ~ +70°C / -22 ~ +158°F, 10 ~ 95% RH							
	VIBRATION	21	10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes						
	SAFETY STANDARDS	UL458 (only for "GFCI" receptacles-Type F) EN60950-1 Bat I/P - AC I/P:3.0KVAC Bat I/P - AC O/P:3.0KVAC AC O/P - FG:1.5KVAC							
AFETY &	WITHSTAND VOLTAGE			U/P:3.0KVAC AC	Compliance to EN55022 class B, 72/ 245/ CEE, 95/ 54/ CE, E-Mar				
MC	EMI CONDUCTION&RADIATION	Compliance to FCC class A			Compliance to EN61000-4-2.3.4.5.6.8.11 ENV50204				
			0.74	1.254		2.7A			
	CHARGE CURRENT (Typ.)	5.5A	2.7A	1.35A	5.5A		1.35A		
HARGER		14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%		
SOLAR CHARGER	MAX OPEN CIRCUIT VOLTAGE		45V	75V	25V	45V	75V		
	CHARGE CURRENT (max.)	30A		571/140/		00.51/1.40/	57) (1.40)		
	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%		
OTHERS	CONTROL WIRING	RJ11-RS232 (Option)							
	DIMENSION	420*220*88mm (L*W*H)							
	PACKING	6.85Kg; 2pcs/14.7Kg/1.61CUFT							
IOTE	3.Output derating capacity re 4.All parameters not specifie	W, linear load at 13V, 26V, 52V input voltage.							



TN-1500 series




1. Installation of TN-1500 unit and PC



WWW.100Y.COM

2.1 Main Page



勝特力材料 886-3-5753170 胜特力电子(上海) 86-21-54151736 胜特力电子(深圳) 86-755-83298787 Http://www. 100y. com. tw

- 1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
- 2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.

WW.100Y.COM.TW

WY.COM.TW

- 3. R.C. Power off: Power can be turned ON or OFF at the remote location.
- 4. Pause: Stop refreshing the page of monitoring software.
- 5. Status of unit: Indicating current operating status of TN-1500.
- 6. Signals that display current condition of the unit.



TN-1500 series

Setting Page							
Inverter Setting	WWW.L	V.COM	N	WW			
File Name	D:\TN_110RR\20071205\REV\TN_110RR\TNF\TN_1K5_512.TNF						
Model name	TN-1500-212						
Manufacture	MeanWell	Series Number	LOC-1234567890 06/23/2007				
Revision	REV:1.10	Date Of Manu.					
I/О Туре	212 🗸	Equalization Volt.	14.3 V	13.5 ~ 15.0V			
Voltage	230 🗸 V	Floating Volt.	13.3 V	13.0 ~ 13.5V			
Frequency	50 🗸 Hz	Alarm Volt.	11.3 V	11.0 ~ 11.5V			
Stand-by saving mode UPS mode Energy saving mode	• On	Shutdown Volt.	10.5 V	10.0 ~ 11.0V			
Comm	Ports 1	Bauds Rate	9600 🔽				
Read	Write Lead						
2	3 4	Read OK!!					

勝	特	力	材	料	886-3-5753170
胜	侍力	电	子(上	海)	86-21-54151736
胜华	時力	电	子(深	圳)	86-755-83298787
	Htt	p :/	//ww	ww.	100y. com. tw

- 1. User can adjust the settings based on the characteristics of batteries been used: Equalization Voltage, Floating Voltage, Alarm Voltage, and Shut-down Voltage. UPS Mode / Energy Saving Mode selection and AC output voltage and frequency can also be set in this page.
- 2. Read: Read current settings of the unit.
- 3. Write: Write the revised setting into the unit.
- 4. Load: Load in factory default settings.

2.3 Statistic Page


verter Setting				
WW.100	COM.	N WW	N.100	1 <u>C</u> O
Start Date 2007/12/07 03	3:13:33 PM	Start Date 2007/12/21	01:40:56 PM	- 00
Inverter time rate	91.2 %	Inverter time rate	31.9 %	
Bypass time rate	0.0 %	Bypass time rate	0.0 %	~10
Shut Down rate	8.8 %	Shut Down rate	68.1 %	<u>00x</u>
Solar time rate	0.0 %	Solar time rate	0.0 %	1
Loading average	24.7 %	Loading average	63.7 %	100
WWW.	100Y.CO	M.TW	MMM.	1.100
RESET	V.100Y.CU	OM.TW	Exit	3.10
WW	Figure	4	WV	N.

- 1. Start Date: Date that installing the monitoring software.
- 2. Reset Date: Date that resetting the statistics. The Start Date will not be influenced by resetting the statistics or turning off the unit.
- 3.Inverter time rate: Operating period of "Inverter Mode" represents how many percent of the whole operating period.
- 4. Bypass time rate: Operating period of "Bypass Mode" (energy provides directly by the utility) represents how many percent of the whole operating period.
- 5. Shut down rate: Percentage of time period that the unit is under the condition of shut down.
- * Inverter time rate + Bypass time rate + Shut down rate = 100%
- 6. Solar time rate: Percentage of time period that the solar charger is functioning after turning on the TN-1500 unit.

WWW.100Y.COM.TW

WY.COM.TW

7. Loading average: Average loading after turning on the TN-1500 unit.



TN-1500 series

