

勝特力材料 886-3-5753170
勝特力电子(上海) 86-21-54151736
勝特力电子(深圳) 86-755-83298787
[Http://www.100y.com.tw](http://www.100y.com.tw)

MHT-18型温湿度计使用说明书

MHT-18型数字温湿度计超薄设计, 小巧精致, 可同时显示温度、湿度, 具有最高、最低温湿度记忆, 摄氏、华氏示值转换等功能。

技术参数:

- ◇ 温度测量范围: $-5^{\circ}\text{C} \sim 50^{\circ}\text{C}$ ($23^{\circ}\text{F} \sim 122^{\circ}\text{F}$)
- ◇ 湿度测量范围: 30%RH~90%RH
- ◇ 显示分辨率: 温度: 0.1°C 湿度: 1%
- ◇ 测量精度: 温度 $\pm 1^{\circ}\text{C}$ 湿度 $\pm 5\%$ (25°C)
- ◇ 电源: DC3.0V 纽扣电池 CR2032一枚

操作说明:

- ◇ 开机: 将开关拨至“ON”, 机器即全显示, 约四秒后显示测量值;
- ◇ 按C/F键, 可进行摄氏华氏温度值转换;
- ◇ 按MEMORY键, 显示记忆中最高温度和湿度, 再按该键, 显示记忆中最低温度和湿度, 继续按该键, 则返回到当前温度和湿度显示模式。在MAX或MIN显示模式时, 若10秒内无按键操作, 则自动返回到当前温度和湿度显示模式。关机后, 再开机可清除最高、最低温湿度记忆值。

注意:

- ◇ 当显示模糊时, 可能是电量不足, 应更换电池。
- ◇ 更换电池: 抽出电池盒, 按极性要求放入电池, 将盒推入即可。

MANUAL (MHT-18 DIGITAL THERMOMETER AND HYGROMETER)

THE PRODUCT IS DESIGNED WITH EXTREMELY THIN BODY AND DELICATE SHAPE. TEMPERATURE AND HUMIDITY CAN BE DISPLAYED SIMULTANEOUSLY. MEMORIZE THE MAX./MIN. VALUES OF TEMPERATURE AND HUMIDITY. SWITCH BETWEEN CELSIUS AND FAHRENHEIT

TECHNICAL PARAMETER:

- ◇ TEMPERATURE MEASURING RANGE: $-5^{\circ}\text{C} \sim 50^{\circ}\text{C}$ ($23^{\circ}\text{F} \sim 122^{\circ}\text{F}$)
- ◇ HUMIDITY MEASURING RANGE: 30%RH-90%RH
- ◇ RESOLUTION: TEMPERATURE: 0.1°C HUMIDITY: 1%
- ◇ ACCURACY: TEMPERATURE $\pm 1^{\circ}\text{C}$, HUMIDITY: $\pm 5\%$ (25°C)
- ◇ POWER: DC3.0V BUTTON BATTERY CR2032

OPERATION DESCRIPTION:

- ◇ **ON/OFF:**
TURN THE BUTTON TO "ON" TO OPEN THE PRODUCT, AND THE MEASURING DATE WILL BE DISPLAYED IN ABOUT 4 SECONDS.
- ◇ **C/F:**
SWITCH BETWEEN CELSIUS OR FAHRENHEIT.
- ◇ **MEMORY:**
PRESS MEMORY BUTTON ONCE AND THE MEMORIED MAXIMUM TEMPERATURE AND HUMIDITY WILL BE DISPLAYED, PRESS AGAIN, MINIMUM TEMPERATURE AND HUMIDITY WILL BE DISPLAYED, PRESS AGAIN, THE PRESENT DATA IS AVAILABLE. NO BUTTON-PRESSING FOR 10 SECONDS, IT WILL AUTOMATICALLY DISPLAY PRESENT DATA. PRESS "POWER OFF" TO CLEAR MEMORIED MAXIMUM TEMPERATURE AND HUMIDITY.
- ◇ **ATTENTION:**
PLEASE REPLACE BATTERY WHEN THE CONTENT ON LCD IS BLUR
BATTERY REPLACEMENT: PULL THE BATTERY BOX OUT AND PUT IN THE BATTERY ACCORDINGLY. PUSH THE BOX BACK.